


RETEVIS



RB20
Network Two Way Radio
USER'S MANUAL

CONTENTS

Open the box and check the device	1
Supplied Accessories	1
Preparation work	1
Installing And Uninstalling Of the Accessories	1
Installing the Lithium battery	1
Attributes of Lithium battery	2
Charging the Lithium battery	2
Installing antenna	2
Installing belt clip	2
Installing SIM card	2
Installing headset	3
Getting to know the radio	3
Introduction	4
Volume selector/ON/OFF switch	4
Push To Talk (PTT) button	4
Indicator light status	4
Basic use	4
Switch ON	4
Switch OFF	4
Volume adjustment	4
Headset	5
Group/Member selection	5
Menu Instruction	5
Select the Group call	5
Select the single call	5
Select the friend	5
GPS	5
Setting	5
Simple troubleshooting	5
Software Instruction	6
IP addresssv	6
Platform Instruction	7
4G LTE smart PTT management platform	7
1. Add the admin, and set the Terminal Number	7
2. Add the device	8
3. Add the order	9
4. Main group and Sub - group	9
5. Renew the account	10
Smart PTT dispatch Management Platform	11
1. In the software, turn on the GPS function	11
2. Menu in the Dispatch management platform	13
3. Interval: 5/10/20/50S	14
Specification	16
Warnings	17


Open the box and check the device

Please remove the radio carefully from the box. We suggest you check the accessories thoroughly according to our list before discarding the packaging. If any part is missing or damaged when you receive it, please contact us.


Supplied Accessories




Radio body



Antenna



battery



USB Cable



Belt clip and Screw

Preparation work

Warning:


- Do not over charge the battery.
If the battery charge is not completed in normal time, please stop charging. The battery may flame, smoke or crack due to an abnormal charging process.
- Do not put the battery in a microwave or high pressure container.
The battery may flame, smoke or crack.
- Do not expose a broken battery to a flame.
If the battery is broken or has an abnormal odour, please remove the battery from the radio and keep it away from any flammable environments. The battery fluid is extremely flammable.
- Do not use abnormal batteries
If the battery is abnormal in odour, colour, shape or in any other form, please remove it from the charger or radio and do not use.
- Please only use charger and adaptor
The charger and adaptor has been designed to be used exclusively with the Radio.
It ensures safety and reliability when charging the battery.

Installing And Uninstalling Of the Accessories

Installing the Lithium battery

Charge before use.

To reduce electrical emission in the battery, please remove the battery from the radio when not in use and store the battery in a cool dry place. When storing the battery for long periods of time: Remove battery from the radio. If possible, fully charge the battery before storage.



Attributes of Lithium battery

After repeated charging process, the battery capacity will decrease.

The battery degenerates gradually even without being used.

More time is required if charging the battery in cool conditions.

Charging and storage of the battery in relatively warm conditions will jeopardize its service life.

Please do not store the radio inside a vehicle or near heating equipment.

If the duration of the battery shortens significantly, please replace the battery immediately to prevent any fluid leaks.

Charging the Lithium battery

After the AC adaptor is connected and the battery is placed in the charger, the indicator will show red which means the battery is charging. The green light will indicate the battery is fully charged.



The light will turn off if the temperature is too high or low, the battery is damaged, the charger is damaged or the connection is poor.

Installing antenna

Hold the radio and antenna, turn the antenna clockwise until it is tightened.

Installing belt clip

If required, screw the belt clip onto the back of the radios using the two screw holes shown on the image below.



Installing SIM card


Please insert effective SIM card before use, make sure the SIM card can be effective in 4G/3G radio.

Long press volume button to switch off the radio.

Remove the battery by pulling down the latch, then pushing the battery backwards along the guides.


Lift SIM socket cover, place SIM card in the socket in the correct position.

Replace the battery.





Installing headset

Open the cover on the side of the radio to show the headset sockets. Your headset will work immediately after being plugged in.



Getting to know the radio





Introduction

Volume selector/ON/OFF switch Long press volume button to switch ON/OFF the radio.
Clockwise for volume UP, counter clockwise for volume DOWN.

Push To Talk (PTT) button

When the device is standing by (Green light will flashing slowly), press PTT button to initiate a call (red light will go on) During the call, the green light will go on to show successful reception. If not in reception, hold PTT to apply for turn to talk (red light will go on) Release the PTT to end call and go back to standing by.

Indicator light status

The green light goes on after the device is switched on. The green light flashes fast to indicate network searching. In standby mode, the green light flashes every five seconds. The green light remains on for reception, and the red light remains on for transmission.

Basic use

●Switch ON

Long press volume button to switch ON the radio, there will then be a voice prompt. After the radio is successfully switched on, the green light goes on first then flashes to indicate network searching. After the network is connected, there will be a voice prompt.

●Switch OFF

Long press volume button to switch OFF the radio, the light will turn off.

Note: Do not frequently switch between ON and OFF, it may affect the switch function.

●Volume adjustment

Revolve clockwise for volume UP and counter clockwise for volume DOWN.

●Headset

Plug in headset, press the PTT button on headset (if there is one) to initiate a call, release the button to end the call.

●Group/Member selection

Enter Menu and choose Group select/Member select, click right keypad to choose group/member you want to connect with, press Menu keypad to confirm and radio will come with a voice prompt.



Menu Instruction

When insert SIM and set the correct setting on the Platform:

turn on the radio, it will login in the platform automatically, with the voice: welcome to use 4G IP radio, if the account is added in the platform successfully, the radio will have the Voice with the Group and User's name.

Select the Group call

There are 2 methods to start the group call:

1. Long press side key one to enter group select on homepage.
2. Press Menu key to enter the menu-group select, use  or  to choose the desired group.

Select the single call

There are 2 method to start the single call:

1. Short press side key two, to enter the member menu, if there are members online, you can choose the desired one, please add members into your current group first if the group member list is empty.
2. Using the Menu key to enter the menu and press right keypad button to enter the member list, confirm to choose the desired member, if there is member online. Press the PTT key to start the single call, press back key to exit.

Select the friend

1. Add friend: login management platform and edit account to add platform friend.
2. Choose friend, enter Menu-Friend Select and then choose the friend you want to select. Press PTT to start single call and back to exit.

GPS

Checking GPS information: enter the menu, use   key to GPS menu, confirm to check the latitude, longitude and satellite.

Note: GPS only working outside, if it is succeed open, the GPS icon will be white.

Setting

PTT Sound

OFF: When press PTT or release PTT, it will not have PTT sound

ON: when press PTT or release PTT, it will have PTT sound

OFF 2: Backlight: to choose 15s 20s 30s on

About: Version detail

Network: Auto: Suggested to choose this one.

4G mode

3G mode: if the 4G signal is not stable, please change to 3G.

2G mode: For the B5 test only.

Version: POC version: Updated

MCU version: updated

Factory: PASSWORD: checking with your local dealer

Simple troubleshooting

If your radio shows and of the following problems, please check the instructions below and if the problem still persists then contact us.

Poor reception: Possible reasons are signal in your current location is weak or the line is busy. If this happens, please move somewhere with improved signal or wait a while before attempting again.

Echo or noise: A possible reason is that the quality of the network provider is flawed. Please restart the radio, this will let it automatically search for an available network with better quality.

Less battery duration: Possible reasons are using and charging the battery in high temperature conditions or searching for a network constantly in a weak network area. If you are in an area with a weak signal, please temporarily switch OFF the radio.

Unable to connect to a network: Possible reasons are that the SIM card is not effective, poor signal or being out of the network service area. Please try either replacing the SIM card or move to a position that is more open, i.e. if you are in a building, move nearer the window.

User's Manual

Software Instruction Platform Instruction Smart PTT dispatch Management Platform

Software Instruction

IP address

American: 47.254.88.91 / Singapore: 47.74.211.230

1. Create account in programming software

(1) Press the side key 1 then turn on the radio, you will find the screen:

COM write chip

NAME:4027EE8

HOST:114.141.132.4

STATE:

(2) Choose the port:

The screenshot shows a software interface with two main panels. The left panel is titled 'Account writing types' and 'Account writing management'. It has radio buttons for 'programming cable account writing' (selected) and 'on-the-air account writing'. Below are fields for 'MEID', 'server IP' (114.141.132.4), 'dealer password' (*****), 'account ID' (FIFA), 'password' (123456), and 'IP address' (47.254.88.91). There are checkboxes for 'New password setting', 'Private call', 'GPS on/off', and 'Off line beep'. At the bottom are 'Help', 'Read', and 'Write' buttons. The right panel is titled 'Communication port' and 'Language setup'. It has a dropdown for 'port' (COM3) and a dropdown for 'language' (English). Below are instructions and fields for 'Dealer password setup' (old and new passwords), 'GPS on/off setup' (GPS Off selected), and 'APN setup' (name: CTNET, account ID card, password: card). There are 'Read' and 'Write' buttons for each section. At the bottom right are instructions for 'Change power-on screen then write' with a 'Select power-on screen file' field and a 'password' field with a 'Change' button. At the very bottom of the interface, it says 'Port is off already!'.

(3) After finished set up, press write. Then you can see the radio name in the radio's screen.

Platform Instruction

4G LTE smart PTT management platform

Click: Platform website. Using the account and password to enter in, you will find the interface as below:

I: For second level admin, which can not add the device, can only create the third admin or deal with the order issue.

4G LTE | Smart Ptt Management Platform

Richard

- Admin management 2
- Users 1
assignment details
- Order management 2
- System Specification 1
- File data 1
- Instruction 3

Admin ID	Admin name	Admin level	Upper admin	Admin password	Createtime	Max terminal No	Resisted Terminal No	Remark	Operations
12	Richard 01	1	Richard	TYT123	2018-07-04	2	2	123	Modify Delete Assign-the-account Recycle-the-account

Admin ID/Admin name Search

Total 1 records, PageNo 1/Total 1 pages

II: for third level admin

61	OffLine	4GTest	2019FFFA	111111	30	1	2019	2018-07-17	2019-07-17		Show	Edit	Modify
60	OffLine	Betsy3	4GTest	111111	30	1	2019	2018-07-17	2019-07-17		Show	Edit	Modify
58	On line	Betsy 2	2018FFFA	123456	30	1	2019	2018-07-13	2019-07-13		Show	Edit	Modify
50	On line	Betsy	FIFA	123456	30	1	2019	2018-07-12	2019-07-12		Show	Edit	Modify
34	OffLine	456	0012491	111111	30	1	A01	2018-07-05	2019-07-05		Show	Edit	Modify
33	OffLine	123	0003383	111111	30	1	A01	2018-07-05	2019-07-05		Show	Edit	Modify

Name/Account Search

Total 7 records, PageNo 1/Total 1 pages

1. Add the admin, and set the Terminal Number

4G LTE | Smart Ptt Management Platform

- Admin management 2
- Users 1
assignment details
- Device Management 2
- Order management 1
- System Specification 1
- File data 1
- Instruction 3

Add Admin

Admin name

Admin level default is level 2

Admin password

Admin remark

Max terminal No Terminal = radio Number

1.1 for third level admin, add the group first, as below

4GLTE Smart Ptt Management Platform

Richard 01

Add Group

Group Name *Chinese allowed, while it must less than 8 character.

Group Members Account/Username: LTE(0014018) rick01(rick01)

Remark

Save Back to list

can add the previous device directly if not add, just save the group

2. Add the device

Note: Only third level admin can add the device, please kindly contact your upper admin for the Account. There are two methods to add the device: add one by one and add in bulk. Add the device one by one:

Add Device

Name *Chinese allowed, while it must less than 8 character.

Account *Chinese allowed, while it must less than 12 digits. For Bulk add, please modify the Account number.

Account number default is 1, do not need change

First number 1 default is one, do not need change

Password 111111 if need change, please use the software

GPS Cycle 30 every 30 second to updated GPS information to platform

Level 1 Lowest level is 1, higher level, can have transmit priority

Validtime 2019-07-11 15:45:56 *Valid time is 1 year, if renew, please contact authorizer

Remark

User functions Contact list Check location Record Transfer Remote kill Group call Call prohibition

Check all Select call Group alarm Location Hold/Resume To the group member The last group

Default group *Please select group ID.(Click the list to choose.)

Group information Group ID/Group Name: M(5) TYT/LTE(4)

The ID which show in the back of radio default is 1, do not need change

Remote kill and call prohibition do not choose, every function will cost the data, please choose the function according to your requirement

choose the group, and it will show in the left. click the group again, the default group will show the group ID

2.1 Add the device in bulk

add the device in bulk

ID	Status	Username	Account	Password	GPS	Level	Default group	Created time	Valid time	Remark	Users Functions	Edit member list	Operations
32	Offline	LTE	0014018	111111	30	1	TYT01	2019-07-05	2019-07-05		Show	Edit	Modify
31	Offline	rick01	rick01	123456	30	1	TYT01	2019-07-04	2019-07-04		Show	Edit	Modify

Name/Account Search

Total 2 records, Page No 1/Total 1 pages

add the device in bulk

☰	Import device in bulk	← Back to previous device list
---	-----------------------	--------------------------------

选择文件	未选择任何文件	Import	Download Excel template
------	---------	--------	-------------------------

3. Add the order

When the account number is not enough:

If the account quantity not enough support your radios quantity. You can add order then ask your upper level administrator to assign the account. Click "Order management", then click "Add order"

4GLTE | Smart Ptt Management Platform AMERICAN01

Add Order

Add Account: Add number:

Return the surplus account: The returned number: The unregistered terminal number: If you give the customer more account, can recall the account

Renew the account: Please choose the renew account:

Renew the account, and choose the renew time to save

Please choose the renew time: months (Please input the integer). *Note: The renew time will start from that date the account is approved and renew time is 12 months in maximum.

Save Back to list

4. Main group and Sub - group

4GLTE | Smart Ptt Management Platform AMERICAN01

Nested groups definitions

Choose group: 2019 (16) *Main group can be set as sub group of other groups. this is main group

Sub-groups management: there are sub- groups, When main group talking, all sub-groups can hear, Sub-group A and B can not communication to each other, Sub- group can add more than one main group, which ever main groups transmit, all sub-group can hear. Main group A and B can not communication.

Group ID/Group Name:

Save Back to list

4.1 Nested groups definitions

Every group can be merged into a new group; it can also be merged into a new group separately; or be combined with other subgroups. However, new groups that are combined by sub-groups cannot be merged. The new group that merged by subgroups has all members of the subgroup.

Return the surplus account

When the quantity for account has exceed the radios, you can return the accounts to the upper level administrator.

☰ Add Order

Add Account ⓘ Add number:

Return the surplusaccount ⓘ The returned number: The unregistered terminal number: 1

Renew the account ⓘ

Please choose the renew account:

Account/Username

Shane03(Shane03)
Shane02(Shane02)
Shane01(Shane01)

Please choose the renew time:
 months (Please input the integer). *Note: The renew time will start from that date the account is approved and renew time is 12 months in maximum.

Save Back to list

5. Renew the account

When your account want to expand the valid time, you need renew the validity period by this order.

☰ Add Order

Add Account ⓘ Add number:

Return the surplusaccount ⓘ The returned number: The unregistered terminal number: 1

Click "Renew the account"

Please choose the renew account:

to select the device account to renew

Account/Username

Shane03(Shane03)
Shane02(Shane02)
Shane01(Shane01)

Please choose the renew time:
 months (Please input the integer). *Note: The renew time will start from that date the account is approved and renew time is 12 months in maximum.

Save Back to list

After that, click "Save", and you will find this order in the "Order list" When the order type is "Return the surplus account, the previous administrator will approve this order automatic, so that the "order states" will shows "Admin approved", this order is deal with.

When the order type is "Add account or renew the account", you need wait the previous administrator to

Order No	Order type	Previous admin	Operation objects	Order states	Create time	Operations
5	Add account	Shane	Shane01	Waiting allocation admin to approve.	2018-07-13	Order-detail
4	Return the surplusaccount	Shane	Shane01	Admin approved.	2018-07-13	Order-detail

1.6 File data

You can change the password in this interface.

Edit Password	
Old Password	<input type="password" value="*****"/>
New Password	<input type="password"/>
Confirm New Password	<input type="password"/>
<input type="button" value="Save"/> <input type="button" value="Back to list"/>	

Notice: when you want to delete the device in the device list, you need, you need to ask the first-level administrator to delete.

Smart PTT dispatch Management Platform

Note: If the Dispatch management platform has registered, The radio will off-line, The same to the radio on and dispatch management off. we suggested that the Dispatch management account is different with PTT platform.

1. In the software, turn on the GPS function

4G radio account writing tools (Version : 1.0.0.20)

Account writing types

- programming cable account writing
- on-the-air account writing

MEID server IP 114 . 141 . 132 . 4

Account writing management

dealer password *****

account ID FIFA

password 123456

IP address 47 . 254 . 88 . 91

New password setting

Private call GPS on/off Off line beep
choose the GPS on

progress

Communication port Language setup

port COM3 language English

Dealer password setup

old password

new password

GPS on/off setup

GPS Off GPS On

APN setup

name CTNET

account ID card

password card

Change power-on screen

Select power-on screen file

password

Port is off already!

1.1 The dispatcher should select the function for "Check Location" in the platform, so that the dispatcher can get the other radios GPS information.

Contact list **Check location** Record Monitor Remote kill Group call Call prohibition

Users Functions

Check all

Single call Group switch Location Voice record To get the group member The last group

The terminals in private call cannot be called again by third party *All elected functions will consume the data, please open the functions needed.

1.2 The radio should select the function for "Location" in the platform, and the radio should be outdoors to get the location. Also the programming software should be open the GPS

Contact list Check location Record Monitor Remote kill Group call Call prohibition

Users Functions

Check all

Single call Group switch **Location** Voice record To get the group member The last group

The terminals in private call cannot be called again by third party *All elected functions will consume the data, please open the functions needed.

Current group ID *This project is added by clicking on the items in the selected group.

1.3 Set the IP address and GOOGLE/Baidu Map, and login in.

4G radio account writing tools (Version : 1.0.0.20)

Account writing types

programming cable account writing

on-the-air account writing

MEID server IP 114 . 141 . 132 . 4

Account writing management

dealer password *****

account ID FIFA

password 123456

IP address 47 . 254 . 88 . 91

New password setting

Private call GPS on/off Off line beep

progress

Help Read Write

Port is off al

User's name is same as the software

user's name

password

save password auto login

Login Cancel

Setup

suggested Resolution 1920 X 1080

Read Write

IP address

Set the IP same as the software

Map Type: Google map outside China

Google map in China

Baidu map

Language: English

Chinese

Modify Cancel

2. Menu in the Dispatch management platform

2.1 Group list

Group list is in the left of the Dispatch platform, which can show the group available and the member, click the group can show all the member and statue. Right click, can start the Private call/Get location/Get track.




Note: The “P” means that the radio is in this group. When the radio is in the group same as dispatcher, it can receive a group call from dispatcher and transmit a group call to dispatcher.

Notice: the dispatcher will login the default group, if you want to login other group, you need modify the default group.

ID	Status	Username	Account	Password	GPS	Level	Default group	Created time	Valid time	Remark	Users Functions	Edit member list	Operations
57	On line				30	1	4GTest	2018-07-13	2019-07-13		Show	Edit	Modify

2.2 Temporary Group call

This is in the right side of the Menu, which can show the all users which the dispatcher choose, can start the temporary call.



2.3 Group call

To start the group call In the group call, choose the desired group and click twice to enter the group.

Long press the to start the group call


After you choose the private call, Press "PttDown" and you can transmit the radio, and release the "PttDown" to wait for replying. The radio can press "PTT" to reply.

Notice: the continuous transmission maximum time is 50S, when you over 50S, it will exits transmit automatic.

To start the Temporary call

In the Group list, choose the desired member, right click the member, choose the Private call.

Click to cancel temporary group call If it is no one start talking within 10s, The temporary will exit automatically.



2.4 To start the private call

Private call, when the dispatcher choose this function, it can transmit anyone in private call.

Operation:









click one radio you want to speak to, then right click, you can find three options: Private call/Get location/Get track

POC Intelligent dispatch system (Version : 2.1.0.10)

IGTYPILAT Smart PTT Dispatch Management Platform



2.5 Location in the MAP

Function	Instruction
	   Terminal Box selected, use the Rectangular Box or round box to choose the desired area
	Track replay
	Terminal Location
	Map Zoom-in
	Map Zoom-out


Note: The GPS function only works outside, in the common case, it will open within 1 minutes, the weather will affect it.

If the GPS is successful in getting the location, the GPS icon will be black, if not it will be a red icon.

2.6 Get track:

you can check the radio's activity trajectory within a period of time.



Operation:

- 1) Click one radio you want to speak to, then right click, you can find three options: Private call/Get location/Get track
- 2) After you choose the get location, you can see the radio's trajectory on the map. You can also click the  to get track

3. Interval: 5/10/20/50S

It means the radio will upload the GPS information in the chosen time.

4. The activity trajectory records will be saved one month, and every time you can track the activity trajectory within 24 hours, for example, when the start time is 2018-7-18 14: 56: 45, the end time should be within 2018-07-18 14: 56: 46 to 2018-07-19 14: 56: 44

Call type	Group call(Call in)	Caller	Shane02	Call time	2018-07-19 00:00:01	To	2018-07-19 23:59:59	Search	Reply	Export
<input checked="" type="checkbox"/>	Number	Caller	Called one	Call type	Call time	Call duration	Voice recording file (Red means that the file			
<input checked="" type="checkbox"/>	1	#02	Group2	Group call(Call in)	2018-07-19 09:48:41	1s	D:\PocData\Record\20180719\us7-20180719-094841-S			
<input checked="" type="checkbox"/>	2	#02	Group2	Group call(Call in)	2018-07-19 09:48:43	3s	D:\PocData\Record\20180719\us7-20180719-094843-S			
<input checked="" type="checkbox"/>	3	#02	Group2	Group call(Call in)	2018-07-19 09:48:46	3s	D:\PocData\Record\20180719\us7-20180719-094846-S			
<input checked="" type="checkbox"/>	4	#02	Group2	Group call(Call in)	2018-07-19 09:51:21	2s	D:\PocData\Record\20180719\us7-20180719-095121-S			
<input checked="" type="checkbox"/>	5	#02	Group2	Group call(Call in)	2018-07-19 09:51:28	4s	D:\PocData\Record\20180719\us7-20180719-095128-S			
<input checked="" type="checkbox"/>	6	02	Group2	Group call(Call in)	2018-07-19 10:53:03	4s	D:\PocData\Record\20180719\us7-20180719-105303-S			
<input checked="" type="checkbox"/>	7	02	Group2	Group call(Call in)	2018-07-19 10:53:09	3s	D:\PocData\Record\20180719\us7-20180719-105309-S			
<input checked="" type="checkbox"/>	8	02	Group2	Group call(Call in)	2018-07-19 10:53:15	14s	D:\PocData\Record\20180719\us7-20180719-105315-S			
<input checked="" type="checkbox"/>	9	02	Group2	Group call(Call in)	2018-07-19 11:15:17	4s	D:\PocData\Record\20180719\us7-20180719-111517-S			
<input checked="" type="checkbox"/>	10	#02	Group2	Group call(Call in)	2018-07-19 11:15:43	2s	D:\PocData\Record\20180719\us7-20180719-111543-S			
<input checked="" type="checkbox"/>	11	#02	Group2	Group call(Call in)	2018-07-19 11:15:53	2s	D:\PocData\Record\20180719\us7-20180719-111553-S			
<input checked="" type="checkbox"/>	12	02	Group2	Group call(Call in)	2018-07-19 11:15:57	7s	D:\PocData\Record\20180719\us7-20180719-111557-S			
<input checked="" type="checkbox"/>	13	02	Group2	Group call(Call in)	2018-07-19 11:17:20	2s	D:\PocData\Record\20180719\us7-20180719-111720-S			
<input checked="" type="checkbox"/>	14	#02	Group2	Group call(Call in)	2018-07-19 11:17:23	8s	D:\PocData\Record\20180719\us7-20180719-111723-S			
<input checked="" type="checkbox"/>	15	#02	Group2	Group call(Call in)	2018-07-19 11:18:21	17s	D:\PocData\Record\20180719\us7-20180719-111821-S			
<input checked="" type="checkbox"/>	16	#02	Group2	Group call(Call in)	2018-07-19 15:53:11	2s	D:\PocData\Record\20180719\us7-20180719-155311-S			

System Specification

Operating System	Linux
Language	English
Antenna	All networks external antenna, GPS antenna built-in
Display size	1.77Inch SPI color screen, resolution: 128*160
CPU	Quectel
Battery capacity	4000mAh
Rx Sensibility:	-106dbm
Max Tx Power	23dBm-25dBm@all up bits
Working Temperature	-20----+60°C
Storage Temperature	-20----+60°C
Audio output power	2W@10% distortion

European version

LTE FDD B1	TX:1920-1980MHz	RX:2110-2170MHz
LTE FDD B3	TX:1710-1785MHz	RX:1805-1880MHz
LTE FDD B7	TX:2500-2570MHz	RX:2620-2690MHz
LTE FDD B8	TX:880-915MHz	RX:925-960MHz
LTE FDD B20	TX:832-862MHz	RX:791-821MHz
LTE FDD B28	TX:703-748MHz	RX:758-803MHz
LTE TDD B38	TX:2570-2620MHz	RX:2570-2620MHz
LTE TDD B40	TX:2300-2400MHz	RX:2300-2400MHz
LTE TDD B41	TX:2555-2655MHz	RX:2555-2655MHz
WCDMA B1	TX:1920-1980MHz	RX:2110-2170MHz
WCDMA 88	TX:880-915MHz	RX:925-960MHz
GSM	900MHz	1800MHz

American version		
LTE TDD B2	TX:1850-1910MHz	RX:1930-1990MHz
LTE TDD B4	TX:1710-1755MHz	RX:2110-2155MHz
LTE TDD B5	TX:824-849MHz	RX:869-894MHz
LTE TDD B12	TX:699-7160MHz	RX:729-746MHz
LTE TDD B13	TX:777-787MHz	RX:746-756MHz
LTE TDD B14	TX:788-798MHz	RX:758-768MHz
LTE TDD B66	TX:1710-1780MHz	RX:2100-2200MHz
LTE TDD B71	TX:663-698MHz	RX:617-652MHz
WCDMA 82	TX:1850-1910MHz	RX:1930-1990MHz
WCDMA B4	TX:1710-1755MHz	RX:2110-2155MHz
WCDMA 85	TX:824-849MHz	RX:869-894MHz

RF ENERGY EXPOSURE AND PRODUCT SAFETY GUIDE FOR PORTABLE TWO-WAY RADIOS



ATTENTION!

Before using this radio, read this guide which contains important operating instructions for safe usage and RF energy awareness and control for compliance with applicable standards and regulations

This two-way radio uses electromagnetic energy in the radio frequency (RF) spectrum to provide communications between two or more users over a distance. RF energy, which when used improperly, can cause biological damage. All Retevis two-way radios are designed, manufactured, and tested to ensure they meet government-established RF exposure levels. In addition, manufacturers also recommend specific operating instructions to users of two-way radios. These instructions are important because they inform users about RF energy exposure and provide simple procedures on how to control it.

Please refer to the following websites for more information on what RF energy exposure is and how to control your exposure to assure compliance with established RF exposure limits:<http://www.who.int/en/>

Local Government Regulations

When two-way radios are used as a consequence of employment, the Local Government Regulations requires users to be fully aware of and able to control their exposure to meet occupational requirements. Exposure awareness can be facilitated by the use of a product label directing users to specific user awareness information. Your Retevis two-way radio has a RF Exposure Product Label. Also, your Retevis user manual, or separate safety booklet includes information and operating instructions required to control your RF exposure and to satisfy compliance requirements.

Radio License

Governments keep the radios in classification, business two-way radios operate on radio frequencies that are regulated by the local radio management departments (FCC, ISED, OFCOM, ANFR, BFTK, Bundesnetzagentur...)- To transmit on these frequencies, you are required to have a license issued by them. The detailed classification and the use of your two radios, please contact the local government radio management departments. Use of this radio outside the country where it was intended to be distributed is subject to government regulations and may be prohibited.

Unauthorized modification and adjustment

Changes or modifications not expressly approved by the party responsible for compliance may void the user's authority granted by the local government radio management departments to operate this radio and should not be made. To comply with the corresponding requirements, transmitter adjustments should be made only by or under the supervision of a person certified as technically qualified to perform transmitter maintenance and repairs in the private land mobile and fixed services as certified by an organization representative of the user of those services. Replacement of any transmitter component (crystal, semiconductor, etc.) not authorized by the local government radio management departments equipment authorization for this radio could violate the rules.

FCC Requirements:

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference. (Licensed radios are applicable);

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (Other devices are applicable)

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE:

•(If applicable)This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

•(If applicable)This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CE Requirements:

•(Simple EU declaration of conformity) Shenzhen Retevis Technology Co., Ltd. declares that the radio equipment type is in compliance with the essential requirements and other relevant provisions of RED Directive 2014/53/EU and the ROHS Directive 2011/65/EU and the WEEE Directive 2012/19/EU; the full text of the EU declaration of conformity is available at the following internet address: www.retevis.com.

•Restriction Information

This product can be used in EU countries and regions, including: Belgium (BE), Bulgaria (BG), Czech Republic (CZ), Denmark (DK), Germany (DE), Estonia (EE), Ireland (IE), Greece (EL), Spain (ES), France (FR), Croatia (HR), Italy (IT), Cyprus (CY), Latvia (LV), Lithuania (LT), Luxembourg (LU), Hungary (HU), Malta (MT), Netherlands (NL), Austria (AT), Poland (PL), Portugal (PT), Romania (RO), Slovenia (SI), Slovakia (SK), Finland (FI), Sweden (SE) and United Kingdom (UK).

For the warning information of the frequency restriction, please refer to the package or manual section.

•Disposal

The crossed-out wheeled-bin symbol on your product, literature, or packaging reminds you that in the European Union, all electrical and electronic products, batteries, and accumulators (rechargeable batteries) must be taken to designated collection locations at the end of their working life. Do not dispose of these products as unsorted municipal waste. Dispose of them according to the laws in your area.



IC Requirements:

Licence-exempt radio apparatus

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage;
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

RF Exposure Information(if applicable)

- DO NOT operate the radio without a proper antenna attached, as this may damage the radio and may also cause you to exceed RF exposure limits. A proper antenna is the antenna supplied with this radio by the manufacturer or an antenna specifically authorized by the manufacturer for use with this radio, and the antenna gain shall not exceed the specified gain by the manufacturer declared.
- DO NOT transmit for more than 50% of total radio use time, more than 50% of the time can cause RF exposure compliance requirements to be exceeded.
- During transmissions, your radio generates RF energy that can possibly cause interference with other devices or systems. To avoid such interference, turn off the radio in areas where signs are posted to do so.
- DO NOT operate the transmitter in areas that are sensitive to electromagnetic radiation such as hospitals, aircraft, and blasting sites.
- Portable Device, this transmitter may operate with the antenna(s) documented in this filing in Push-to-Talk and body-worn configurations. RF exposure compliance is limited to the specific belt-clip and accessory configurations as documented in this filing and the separation distance between user and the device or its antenna shall be at least 2.5 cm.
- Mobile Device, during operation, the separation distance between user and the antenna subjects to actual regulations, this separation distance will ensure that there is sufficient distance from a properly installed externally-mounted antenna to satisfy the RF exposure requirements.
- Occupational/Controlled Radio, this radio is designed for and classified as "Occupational/Controlled Use Only", meaning it must be used only during the course of employment by individuals aware of the hazards, and the ways to minimize such hazards; NOT intended for use in a General population/uncontrolled environment.
- General population/uncontrolled Radio, this radio is designed for and classified as "General population/uncontrolled Use".

RF Exposure Compliance and Control Guidelines and Operating Instructions

To control your exposure and ensure compliance with the occupational/controlled environment exposure limits, always adhere to the following procedures.

Guidelines:

- User awareness instructions should accompany the device when transferred to other users.
- Do not use this device if the operational requirements described herein are not met.

Operating Instructions (if applicable):

- Transmit no more than the rated duty factor of 50% of the time. To Transmit (Talk), push the Push to Talk (PTT) button. To receive calls (listen), release the PTT button. Transmitting 50% of the time, or less, is important because the radio generates measurable RF energy exposure only when transmitting in terms of measuring for standards compliance.
- Transmit only when people outside the vehicle are at least the recommended minimum lateral distance away from a properly installed according to installation instructions, externally mounted antenna.
- When operating in front of the face, worn on the body, always place the radio in a Retevis approved clip, holder, holster, case, or body harness for this product. Using approved body-worn accessories is important because the use of Non-Retevis approved accessories may result in exposure levels, which exceed the IEEE/ICNIRP RF exposure limits.

Hand-held Mode(if applicable)

- Hold the radio in a vertical position with the microphone (and other parts of the radio including the antenna) at least 2.5 cm (one inch) away from the nose or lips. The antenna should be kept away from the eyes. Keeping the radio at a proper distance is important as RF exposure decreases with increasing distance from the antenna.

Phone Mode(if applicable)

- When placing or receiving a phone call, hold your radio product as you would a wireless telephone. Speak directly into the microphone.

Electromagnetic Interference/Compatibility

NOTE: Nearly every electronic device is susceptible to electromagnetic interference (EMI) if inadequately shielded, designed, or otherwise configured for electromagnetic compatibility.



Avoid Choking Hazard



Small Parts. Not for children under 3 years.

Turn off your radio power in the following



WARNING

- Turn off your radio before removing (installing) a battery or accessory or when
- Turn off your radio when you are in a potentially hazardous environments: Near electrical blasting caps, in a blasting area, in explosive atmospheres (flammable gas, dust particles, metallic powders, grain powders, etc.).
- Turn off your radio while taking on fuel or while parked at gasoline service stations. To avoid electromagnetic interference and/or compatibility conflicts
- Turn off your radio in any facility where posted notices instruct you to do so, hospitals or health care facilities (Pacemakers, Hearing Aids and Other Medical Devices) may be using equipment that is sensitive to external RF energy.
- Turn off your radio when on board an aircraft. Any use of a radio must be in accordance with applicable regulations per airline crew instructions.

Protect your hearing:



WARNING

- Use the lowest volume necessary to do your job.
 - Turn up the volume only if you are in noisy surroundings.
 - Limit the amount of time you use headsets or earpieces at high volume.
 - When using the radio without a headset or earpiece, do not place the radio's speaker directly against your ear
 - Use careful with the earphone maybe possible excessive sound pressure from earphones and headphones can cause hearing loss
- Note:** Exposure to loud noises from any source for extended periods of time may temporarily or permanently affect your hearing. The louder the radio's volume, the less time is required before your hearing could be affected. Hearing damage from loud noise is sometimes undetectable at first and can have a cumulative effect.



Avoid Burns



WARNING

Antennas

- Do not use any portable radio that has a damaged antenna. If a damaged antenna comes into contact with the skin when the radio is in use, a minor burn can result.

Batteries (If appropriate)

- When the conductive material such as jewelry, keys or chains touch exposed terminals of the batteries, may complete an electrical circuit (short circuit the battery) and become hot to cause bodily injury such as burns. Exercise care in handling any battery, particularly when placing it inside a pocket, purse or other container with metal objects

Long transmission

- When the transceiver is used for long transmissions, the radiator and chassis will become hot. charging battery.

Safety Operation



WARNING

Forbid

- Do not use charger outdoors or in moist environments, use only in dry locations/conditions.
- Do not disassemble the charger, that may result in risk of electrical shock or fire.
- Do not operate the charger if it has been

broken or damaged in any way.

- Do not place a portable radio in the area over an air bag or in the air bag deployment area. The radio may be propelled with great force and cause serious injury to occupants of the vehicle when the air bag inflates.

To reduce risk

- Pull by the plug rather than the cord when disconnecting the charger.
- Unplug the charger from the AC outlet before attempting any maintenance or cleaning.
- Contact Retevis for assistance regarding repairs and service.
- The adapter shall be installed near the equipment and shall be easily accessible

Approved Accessories



WARNING

- This radio meets the RF exposure guidelines when used with the Retevis accessories supplied or designated for the product. Use of other accessories may not ensure compliance with the RF exposure guidelines and may violate regulations.
- For a list of Retevis-approved accessories for your radio model, visit the following website: <http://www.Retevis.com>

EU Importer:

Name: Germany Retevis Technology GmbH

Address: Uetzenacker 29,38176 wendeburg

For downloading further resources: Brochures, Software/Firmware, Manual etc, Pls contact your direct reseller first OR go to website retevis.com and check "support" in the each product link to download it.

RETEVIS

Guarantee

Model Number: _____ Serial Number: _____

Purchasing Date: _____

Dealer: _____ Telephone: _____

User's: _____ Telephone: _____

Country: _____ Address: _____

Post Code: _____ Email: _____

Remarks:


1. This guarantee card should be kept by the user, no replacement if lost.
2. Most new products carry a two-year manufacturer's warranty from the date of purchase. Further details, pls read <http://www.retevis.com/after-sale/>
3. The user can get warranty and after-sales service as below:
 - Contact the seller where you buy.
 - Products Repaired by Our Local Repair Center
4. For warranty service, you will need to provide a receipt proof of purchase from the actual seller for verification

Exclusions from Warranty Coverage:

1. To any product damaged by accident.
2. In the event of misuse or abuse of the product or as a result of unauthorized alterations or repairs.
3. If the serial number has been altered, defaced, or removed.

Cut along this line





CE FC RoHS



Shenzhen Retevis Technology Co.,Ltd.

Add: 7/F, 13-C, Zhonghaixin Science&Technology Park, No.12 Ganli
6th Road, Jihua Street, Longgang District, Shenzhen, China

Web: www.retevis.com

E-mail: kam@retevis.com

Facebook: facebook.com/retevis



MADE IN CHINA

说明书要求

尺寸：120*160mm

印刷：

- 1、黑白印刷
- 3、内页黑白印刷

装订：钉装

纸张材质：

- 1、普通印刷纸

Sh

本页无需印刷